

FCC Statement

Your radio might cause TV or radio interference even when it is operating properly. To determine whether your radio is causing the interference, turn it off. If the interference goes away, your radio is causing it. Try to eliminate the interference by:

- Moving your radio away from the receiver
- Contacting your local RadioShack store for help

If you cannot eliminate the interference, the FCC requires that you stop using the radio.

Caring for Your Radio

To enjoy your radio for a long time:

- Handle it gently.
- Keep it away from dust, moisture, and temperature extremes.
- Clean it with a damp cloth. Do not use harsh chemicals.
- Do not take it apart. If something is wrong with the radio, take it to your local RadioShack store for assistance.

RadioShack Limited Warranty

This product is warranted against defects for 90 days from date of purchase from RadioShack company-owned stores and authorized RadioShack franchisees and dealers. Within this period, we will repair it without charge for parts and labor. Simply **bring your RadioShack sales slip** as proof of purchase date to any RadioShack store. Warranty does not cover transportation costs. Nor does it cover a product subjected to misuse or accidental damage.

EXCEPT AS PROVIDED HEREIN, RadioShack MAKES NO EXPRESS WARRANTIES AND ANY IMPLIED WARRANTIES ARE LIMITED IN DURATION TO THE DURATION OF THE WRITTEN LIMITED WARRANTIES CONTAINED HEREIN. Some states do not permit limitation or exclusion of implied warranties; therefore, the aforesaid limitation(s) or exclusion(s) may not apply to the purchaser.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

We Service What We Sell

10/95

RadioShack

**A Division of Tandy Corporation
Fort Worth, Texas 76102**

2A6

Printed in the Philippines



RadioShack™

AM/FM Cool Cube Radio

**n Easy To Use
n Convenient Carrying Handle**

Owner's Manual

Cat. No. 12-208

INSTALLING BATTERIES

Four AA Batteries
(Cat. No. 23-552)

Cautions:

- Match the polarity symbols (+ and –) marked inside the battery compartment.
- Always use fresh batteries of the required size and type.

USING THE RADIO

Telescoping Antenna — extend for the best FM reception

Note: The AM antenna is built-in. For the best AM reception, rotate the radio.

TUNING — rotate to select your favorite station

FM/AM — switch to select the band

VOLUME — rotate to turn the radio on and off and adjust the volume

© 1996 Tandy Corporation.
All Rights Reserved.
RadioShack is a trademark used by Tandy Corporation.